## LEM card-stock tube holder is helpful or necessary.

Small variations in tube position can influence readings.



Firstly make sure the card-stock material you have is non-reactive to the LEM.

Then cut out and insert ends of the card-stock or light cardboard strip between the LM4 and the rubber case, adjusting so the hole is directly above the center of the blue square, arcing up between 1-2 cm.

Length: 5" Width: 1.5"

Hole, centered with 3/4" diameter or slightly larger, to allow easy insertion and removal of the glass vials you are using. (Bad photo, should not have other water samples sitting so close!)

